

495/495P SPECTRUM ANALYZER

Qservice ----- This document is a complete scan from the original manual ----- Qservice

Please Check for CHANGE INFORMATION at the Rear of This Manual

First Printing MAY 1986

Tektronix[®]
COMMITTED TO EXCELLENCE

PREFACE

This manual is one of a set of product manuals for the TEKTRONIX 495 and programmable 495P Spectrum Analyzer. The manual describes the instrument installation and operation. These instructions assume a thorough knowledge of frequency domain analysis. The purpose of this manual is to explain the operation of the spectrum analyzer so that measurements will be meaningful whether made under adverse or laboratory conditions. The manual organization is shown in the Table of Contents. The manuals that are available now in addition to this Operators Manual are the

- 495/495P Service Manuals, Volume 1 and 2 (standard accessories) and
- 495P Programmers Manual (standard accessory for 495P only).

There will be two additional publications available shortly; 495/495P Operators Handbook (optional accessory), and a Programmers Reference Guide. For manual ordering information, contact your local Tektronix Field Office or representative or refer to the Accessories portion of the Replaceable Mechanical Parts list in the Service Manual, Volume 2.

Standards and Conventions Used

Most terminology is consistent with standards adapted by IEEE and IEC. A glossary of terms is provided in Appendix A. Abbreviations in the documentation are consistent with ANSI Y1.1-1972. GPIB functions conform to the IEEE 488-1978 Standard. Copies of ANSI and IEEE standards can be ordered from the Institute of Electrical and Electronic Engineers Inc.

Change/History Information

Any change information that involves manual corrections or additional information is located behind the tabbed Change Information page at the back of this manual.

History information, as well as the updated data, is combined within this manual when the page(s) is revised. A revised page is identified by a revision date located in the lower inside corner of the page.

Unpacking and Initial Inspection


Instructions for unpacking and preparing the instrument for use are described in Section 3.

Storage and Repackaging

Instructions for short- and long-term storage and instrument repackaging for shipment are described in Section 3.

TABLE OF CONTENTS

	Page		Page
PREFACE.....	i	Section 4 (continued)	
TABLE OF CONTENTS.....	ii	Correcting Numerical Entry Errors	4-2
LIST OF ILLUSTRATIONS	iv	Instrument Power Control and	
LIST OF TABLES.....	v	Frequency.....	4-3
SAFETY SUMMARY	vi	Frequency Span and Resolution.....	4-5
Section 1 GENERAL INFORMATION		Marker Functions	4-7
Product Overview	1-1	Display Parameters	4-14
Firmware Version and Error Message		Sweep	4-17
Readout	1-1	Digital Storage.....	4-19
Accessories	1-1	Display and General Purpose	4-21
Options	1-2	Front-panel Input/Output and GPIB.....	4-24
Section 2 SPECIFICATION		Rear-panel Input/Output and GPIB.....	4-26
Electrical Characteristics.....	2-1	Section 5 INSTRUMENT CHECK OUT	
Verification of Tolerance Values.....	2-1	Firmware Version and Error Message	
Frequency Related Characteristics	2-1	Readout.....	5-1
Amplitude Related Characteristics	2-4	Firmware Version.....	5-1
Input Signal Characteristics	2-8	Error Message Readout.....	5-1
Output Signal Characteristics.....	2-10	Preparation for Use	5-1
General Characteristics.....	2-11	1. Initial Turn On	5-1
Power Requirements.....	2-11	2. Calibrate Position, Center	
Environmental Characteristics.....	2-12	Frequency, Reference Level, and	
Physical Characteristics	2-13	Bandwidth	5-2
Section 3 PREPARATION FOR USE		Functional or Operational Check	5-3
Unpacking and Initial Inspection.....	3-1	Equipment Required.....	5-3
Installation.....	3-1	Preliminary Preparation.....	5-3
Rackmount Instrument.....	3-1	1. Check Operation of Front-Panel	
Rack Adapter Kit.....	3-2	Pushbuttons and Controls.....	5-3
Power Source and Power		2. Check Gain Variation Between	
Requirements	3-2	Resolution Bandwidths	5-10
Storage and Repackaging	3-2	3. Check Span Accuracy and	
Storage	3-2	Linearity	5-11
Repackaging for Shipment.....	3-2	4. Check Resolution Bandwidth and	
Transit Case.....	3-2	Shape Factor.....	5-11
Section 4 CONTROLS, CONNECTORS,		5. Check Reference Level Gain and	
AND INDICATORS		RF Attenuator Steps	5-12
Operating Modes.....	4-1	6. Check Sensitivity.....	5-12
Initial Entry Functions (Black Labels) ..	4-1	7. Check Residual FM.....	5-13
Multiple-Pushbutton Sequence		8. Check Frequency Drift or	
Functions (SHIFT Pushbuttons).....	4-1	Stability	5-13
Terminating Multiple-Pushbutton		9. GPIB Verification Program	5-13
Sequences	4-1	Section 6 OPERATION	
DATA ENTRY Functions (Orange		Instrument Operating Features.....	6-1
Labels)	4-2	Firmware Version and Error Message	
		Readout	6-1
		Crt Light Filters	6-1
		Intensity Level and Beam Alignment ..	6-1
		Signal Application	6-1
		⚠ RF INPUT Connector	6-1

	Page
Section 6 (continued)	
Resolution Bandwidth, Frequency Span, and Sweep Time	6-2
Using the HELP Feature.....	6-3
Using the Signal Identifier.....	6-3
Using the Video Filters.....	6-4
Using Time Domain Operation	6-4
Triggering the Display.....	6-4
Sweeping the Display.....	6-5
Manual Scan of the Spectrum.....	6-5
Reference Level, RF Attenuation, and Vertical Display	6-5
Alternate Reference Level Units Selection	6-6
Using the Delta A Mode	6-6
Using MIN NOISE or MIN DISTORTION.....	6-6
Using Digital Storage	6-6
Using the Store and Recall Features ..	6-7
Using the Counter	6-8
Plotting the Display.....	6-8
Using the Markers Feature	6-8
Marker Terms	6-8
Marker Turn On.....	6-8
Marker Menu and Assign Menu	6-9
Assigning Markers	6-9
Tuning Markers	6-9
Error Detection.....	6-10
Using the Automatic Performance Testing Feature.....	6-10
Using the Tracking Generator Mode ..	6-10
Using the Sideband Analyzer Mode ..	6-10
Programming Features (495P GPIB Operation).....	6-11
Setting GPIB Address Switches.....	6-11
TALK ONLY, LISTEN ONLY Switches.....	6-11
Connecting to a System.....	6-11
Operational Considerations/Precautions	6-11
1.  RF INPUT Power Limit.....	6-11
2. Instrument Warm-up After Storage	6-11
3. Auto Resolution.....	6-11

	Page
Section 6 (continued)	
4. Level of Pulsed Signals.....	6-11
5. Level of Continuous Wave Signals.....	6-12
6. Excessive Input Signal Level.....	6-12
7. No Crt Trace	6-12
8. PEAK/AVERAGE.....	6-12
9. Digital Storage Effects on Signal Analyses.....	6-12
10. Stored Display Averaged in Wide Spans	6-12
11. Automatic Calibration of Relative Amplitudes of Resolution Bandwidth Filters	6-12
12. TRIGGERING	6-12
Service Information	6-12
Service Manual.....	6-12
Product Service.....	6-13
Emergency Repair.....	6-13
Maintenance Agreements.....	6-13
Section 7 OPTIONS	
Options A1–A5 (Power Cord Options).....	7-1
Options M1–M3 (Extended Service and Warranty Options)	7-1
Option 05 (Provides frequency counter and macros).....	7-2
Option 07 ! (Provide 75 Ω Input).....	7-2
Options 30 and 31 (Provide Rackmount).....	7-3
Option 39 (Provide Silver Battery).....	7-5
Option 42 (Provide 110 MHz IF Output)	7-5
Option 45 (Provide MATECO Capability)	7-5
Option 52 (Provide North American 220 V).....	7-5
Appendix A GLOSSARY	
General Terms.....	A-1
Terms Related to Frequency	A-1
Terms Related to Amplitude	A-2
Terms Related to Digital Storage.....	A-3
Terms Related to Markers.....	A-3

LIST OF TABLES

Table Number	Page	Table Number	Page
2-1	Frequency Related Characteristics.....	2-1	
2-2	Amplitude Related Characteristics.....	2-4	
2-3	Input Signal Characteristics.....	2-8	
2-4	Output Signal Characteristics.....	2-10	
2-5	General Characteristics.....	2-11	
2-6	Power Requirements.....	2-11	
2-7	Environmental Characteristics.....	2-12	
2-8	Physical Characteristics.....	2-13	
5-1	Sensitivity.....	5-12	
6-1	50 Ω System Reference Level Conversion.....	6-2	
6-2	Marker Trace Organization.....	6-10	
7-1	Power Cord Options.....	7-1	
7-2	Extended Service and Warranty Options.....	7-2	
7-3	Option 07 Alternate Specifications.....	7-2	
7-4	Options 30 and 31 Characteristics and Alternate Specifications.....	7-4	
7-5	Option 42 Alternate Specifications.....	7-5	

LIST OF ILLUSTRATIONS

Figure Number	Page	Figure Number	Page
2-1	Dimensions.....	2-15	
4-1	Instrument Power Control and Frequency.....	4-3	
4-2	Frequency Span and Resolution.....	4-5	
4-3	Marker Functions.....	4-7	
4-4	Locating the signal peak.....	4-8	
4-5	Using <green-SHIFT> PEAK FIND.....	4-10	
4-6	Signal finding example.....	4-11	
4-7	Signal finding example.....	4-12	
4-8	Signal finding example.....	4-12	
4-9	Signal finding example.....	4-13	
4-10	Signal finding example.....	4-13	
4-11	Display Parameters.....	4-14	
4-12	Sweep.....	4-17	
4-13	Digital Storage.....	4-19	
4-14	Display and General Purpose.....	4-21	
4-15	Front-Panel Input/Output and GPIB.....	4-24	
4-16	Rear-Panel Input/Output and GPIB.....	4-26	
5-1	Crt display and readout at initial turn on.....	5-1	
5-2	Typical display of calibration markers in the maximum span position.....	5-2	
5-3	Integrating a display with the VIDEO FILTER.....	5-5	
5-4	Using the IDENT feature to identify a real or true response.....	5-6	
5-5	Displays that illustrate how bandwidth and shape factor are determined.....	5-11	
5-6	Typical display showing how to determine residual FM.....	5-14	
6-1	Circuit of a 75 to 50 Ω matching pad (ac coupled).....	6-2	
6-2	Graph illustrating the relationship between dBm, dBmV, and dB.....	6-2	
6-3	Volts-dBm-Watts conversion chart for 50 Ω impedance.....	6-3	
6-4	Typical example of Identifier mode displays.....	6-4	
6-5	Typical display mixed with the VIDEO FILTER.....	6-5	
6-6	Typical display using B-SAVE A to observe the difference between SAVE A and B displays.....	6-7	
7-1	International power cord options for the spectrum analyzer.....	7-1	

POWER

Power Source

This product is intended to operate from a power source that will not apply more than 250 V rms between the supply conductors or between either supply conductor and ground. A protective ground connection by way of the grounding conductor in the power cord is essential for safe operation.

Grounding the Product

This product is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before connecting it to the product input or output terminals. A protective ground connection by way of the grounding conductor in the power cord is essential for safe operation.

Danger From Loss of Ground

Upon loss of the protective-ground connection, all accessible conductive parts (including knobs and controls that may appear to be insulating) can render an electric shock.

Use the Proper Power Cord

Use only the power cord and connector specified for your product.

Use only a power cord that is in good condition.

Refer cord and connector changes to qualified service personnel.

For detailed information on power cords and connectors, see the Maintenance section in the Service Manual, Volume 1.

Use the Proper Fuse

To avoid fire hazard or equipment damage, use only the fuse of correct type, voltage rating, and current rating for your product (as specified in the Replaceable Electrical Parts list in Volume 2 of the Service Manual). Refer fuse replacement to qualified service personnel.

OPERATIONAL PRECAUTIONS

Do Not Operate in Explosive Atmospheres

To avoid explosion, do not operate this product in an explosive atmosphere unless it has been specifically certified for such operation.

Do Not Remove Covers or Panels

To avoid personal injury, do not remove the product covers or panels unless you are qualified to do so. Do not operate the product without the covers and panels properly installed.

Dangerous voltages exist at several points in this product. To avoid personal injury, do not touch exposed connections and components while power is on. REFER ALL SERVICING TO QUALIFIED SERVICE PERSONNEL.