



OPERATING AND SERVICE MANUAL

MODEL 211A

SERIALS PREFIXED: 026 -

SQUARE WAVE GENERATOR

Reproduced With Permission Courtesy Agilent Technologies, Inc.

Copyright HEWLETT-PACKARD COMPANY 1955
1501 PAGE MILL ROAD, PALO ALTO, CALIFORNIA, U. S. A.



TABLE OF CONTENTS

| Section | Page | Section | Page |
|--|------|---|------|
| I GENERAL INFORMATION | 1-1 | IV MAINTENANCE | 4-1 |
| 1-1. General Description | 1-1 | 4-1. Introduction | 4-1 |
| 1-9. Damage in Transit | 1-2 | 4-3. Cabinet Removal | 4-1 |
| 1-11. Power Transformer Conversion | 1-2 | 4-5. Equipment Required | 4-1 |
| | | 4-7. Trouble Localization | 4-1 |
| II OPERATING INSTRUCTIONS | 2-1 | 4-12. Tube Replacement | 4-1 |
| 2-1. Controls and Terminals | 2-1 | 4-15. Adjusting the Power Supply | 4-1 |
| 2-11. Instrument Loading | 2-1 | 4-20. Frequency Calibration | 4-4 |
| 2-17. Ringing | 2-1 | 4-24. Adjusting External Sync Sensitivity Sync Sensitivity | 4-7 |
| 2-19. External Sync Operation | 2-1 | 4-27. Waveform Observation and Measurement | 4-7 |
| 2-22. Pulses | 2-3 | 4-41. Servicing Etched Circuit Boards | 4-8 |
| 2-24. Balanced Output | 2-3 | | |
| III THEORY OF OPERATION | 3-1 | V REPLACEABLE PARTS | 5-1 |
| 3-1. Introduction | 3-1 | 5-1. Introduction | 5-1 |
| 3-3. Sync Trigger | 3-1 | 5-2. Ordering Information | 5-1 |
| 3-7. Multivibrator | 3-1 | | |
| 3-12. Clipper Amplifier | 3-1 | | |
| 3-15. Power Amplifier | 3-2 | | |

LIST OF ILLUSTRATIONS

| Number | Page | Number | Page |
|---|------|--|------|
| 2-1. Common Impedance Matching Networks | 2-1 | 4-2. Model 211A Top View | 4-5 |
| 2-2. Front Panel Showing Operating Controls | 2-2 | 4-3. Test Setup for Frequency Calibration | 4-6 |
| 2-3. Basic Output Circuit of 211A | 3-1 | 4-4. Test Setup for Sync Sensitivity | 4-6 |
| 2-4. Method of Obtaining a Balanced Output from the 211A | 3-3 | 4-5. 75-Ohm Output Waveform which has Defects on Positive Portion | 4-8 |
| | | 4-6. Model 211A Waveforms | 4-9 |
| 3-1. Block Diagram Showing Operating Controls of 211A | 3-0 | 4-7. Voltage and Resistance Diagram | 4-10 |
| | | 4-8. Multivibrator and Power Supply | 4-11 |
| 4-1. Model 211A Bottom View Showing Amplifier and Power Supply | 4-2 | 4-9. Output Section | 4-12 |
| | | 4-10. Range Switch Detail | 4-13 |
| | | 4-11. Attenuator Switch Detail | 4-14 |

LIST OF TABLES

| Number | Page |
|--|------|
| 1-1. Specifications | 1-1 |
| 4-1. Tube Replacement Chart | 4-0 |
| 4-2. Test Equipment Required | 4-1 |
| 4-3. Troubleshooting Chart | 4-3 |
| 4-4. Calibration Chart | 4-4 |
| 5-1. Reference Designation Index | 5-2 |
| 5-2. Replaceable Parts | 5-7 |