



HEWLETT-PACKARD COMPANY // OPERATING AND SERVICE MANUAL

**403B
403B-DB
TRANSISTORIZED
AC VOLTMETER**

Reproduced With Permission Courtesy Agilent Technologies, Inc.



OPERATING AND SERVICE MANUAL

MODEL 403B/403B-db

SERIALS PREFIXED: 225

TRANSISTORIZED
AC VOLTMETER

Qservice sample file

Copyright Hewlett-Packard Company 1962



TABLE OF CONTENTS

Section	Page	Section V (Cont'd)	Page
I GENERAL INFORMATION	1-1	4-20. Meter Rectifier Circuit	4-2
1-1. Description	1-1	4-25. Power Supply	4-3
1-5. Differences Between Instruments	1-2		
1-7. Accessories Available	1-2	Section	Page
Section	Page	V MAINTENANCE	5-1
II INSTALLATION	2-1	5-1. Introduction	5-1
2-1. Inspection	2-1	5-6. Test Instruments Required	5-1
2-4. Power Requirements	2-1	5-8. Meter, Mechanical Zero	5-2
2-6. Installation	2-1	5-10. Troubleshooting	5-2
2-8. Repackaging for Shipment	2-1	5-12. Repair	5-3
Section	Page	5-13. Cabinet Removal	5-3
III OPERATING INSTRUCTIONS	3-1	5-14. Servicing Etched Circuit Boards	5-3
3-1. Introduction	3-1	5-16. Transistor Replacement	5-3
3-3. Front Panel Description	3-1	5-18. Function Switch Repair	5-3
3-5. Operating Procedure	3-1	5-20. Fluorescent Indicator Decal	5-5
3-7. Battery Charging Information	3-1	5-22. Adjustments	5-5
3-9. Instrument Temperature Limits	3-1	5-25. Power Supply	5-5
3-11. Input Protection Fuse	3-1	5-26. Input Resistance	5-7
3-13. Voltage Measurements	3-1	5-28. Overload Check	5-7
3-18. Waveform Errors	3-3	5-29. Tracking and Calibration	5-7
3-21. Decibel Measurements	3-3	5-30. High Frequency Response	5-8
3-24. Impedance Correction Graph	3-4	5-31. 30-Volt Response	5-8
3-27. Current Measurements	3-4	5-32. Low Frequency Response	5-8
3-28. Shunt Resistors	3-4	5-34. Performance Check	5-8
3-31. Clip-On Probe	3-4	5-36. Calibration	5-9
Section	Page	5-37. High Frequency Response	5-9
IV CIRCUIT DESCRIPTION	4-1	5-39. Low Frequency Response	5-9
4-1. Introduction	4-1	5-40. Noise Check	5-9
4-3. Preliminary Attenuator	4-1	5-41. Input Resistance	5-10
4-6. Input Circuit	4-1	Section	Page
4-11. Intermediate Attenuator	4-2	VI REPLACEABLE PARTS	6-1
		6-1. Introduction	6-1
		6-4. Ordering Information	6-1

LIST OF TABLES

Number	Page	Number	Page
1-1. Specifications	1-1	5-2. Troubleshooting	5-3
1-2. Accessories Available	1-2	5-3. Test Procedure Troubleshooting	5-3
3-1. Effect of Harmonics on Model 403B Voltage Measurements	3-3	5-4. Transistor Replacement	5-5
3-2. Examples of Voltage and DB Measurements	3-3	5-5. Calibration Table	5-9
5-1. Test Instruments Required	5-1	6-1. Index by Reference Designator	6-2
		6-2. Replaceable Parts	6-8

LIST OF ILLUSTRATIONS

Number	Page	Number	Page
1-1. Models 403B and 403B-db Transistorized AC Voltmeters	1-0	4-5. Meter Rectifier, Simplified Diagram	4-3
3-1. Front Panel Description	3-0	4-6. Meter Rectifier Circuit	4-3
3-2. Voltage Measurements	3-2	5-1. Model 403B Top View	5-0
3-3. Model 403B Impedance Correction Graph	3-4	5-2. Model 403B Bottom View	5-2
4-1. Model 403B Functional Block Diagram	4-0	5-3. Function Switch Detail	5-4
4-2. Input Amplifier	4-1	5-4. Range Switch Details	5-6
4-3. Diode Current Vs Diode Voltage	4-2	5-5. Overload Check Setup	5-7
4-4. Fixed Amplifier Block Diagram	4-2	5-6. Performance Check Setup	5-7
		5-7. Frequency Response Setup	5-8
		5-8. Schematic Diagram	5-11/5-12
		6-1. Exploded View	6-7