

Tektronix[®]
COMMITTED TO EXCELLENCE

**PLEASE CHECK FOR CHANGE
INFORMATION AT THE REAR
OF THIS MANUAL.**

434
OSCILLOSCOPE
OPERATORS

Tektronix, Inc.
P.O. Box 500
Beaverton, Oregon 97077

070-1142-01

INSTRUCTION MANUAL
First Printing AUG 1971
Serial Number _____ Revised AUG 1981

TABLE OF CONTENTS

| | Page | | Page |
|--------------------------------------|------|--|------|
| Introduction | | | |
| General | 1 | Vertical GAIN | 16 |
| Operating Voltage | 1 | ASTIGmatism and FOCUS | 16 |
| Operating Temperature | 2 | Basic Timing | 16 |
| Operating Position | 2 | Applications | |
| Controls and Connectors | | General | 16 |
| General | 2 | DC Voltage Level Measurement | 17 |
| Detailed | 3 | Peak-To-Peak Voltage Measurement – AC | 18 |
| Basic Operation | | Comparison Measurements | 20 |
| General | 10 | Time-Duration Measurements | 22 |
| Non-Store Display | 10 | Frequency Measurement | 24 |
| Magnified Sweep Display | 11 | Risetime Measurements | 24 |
| External Horizontal Display | 11 | Time-Difference Measurements | 25 |
| Normal Storage Display | 12 | Multi-Trace Difference Measurements | 27 |
| Single-Sweep Storage | 12 | X-Y Phase Measurement | 29 |
| Integrated Fast-Rise Waveforms | 13 | Common-Mode Rejection | 30 |
| Fast Single-Sweep Enhancement | 13 | | |
| User's Calibration | | | |
| General | 15 | Abbreviations and symbols used in this manual are based on or taken directly from IEEE Standard 260 'Standard Symbols for Units', MIL-STD-12B and other standards of the electronics industry. Change information, if any, is located at the rear of this manual. | |
| Trace Rotation | 15 | | |
| STEP ATTENuator BALance | 15 | | |
| Probe Compensation | 15 | | |