



TEKTRONIX®

**607
MONITOR**

WITH OPTIONS

OPERATORS

INSTRUCTION MANUAL

Tektronix, Inc.
P.O. Box 500
Beaverton, Oregon 97077

Serial Number _____

TABLE OF CONTENTS

	PAGE
LIST OF ILLUSTRATIONS	ii
LIST OF TABLES.	ii
SAFETY SUMMARY.	iii
SECTION 1 GENERAL INFORMATION	
INTRODUCTION	1-1
PACKAGING FOR SHIPMENT	1-1
SPECIFICATION	1-2
STANDARD ACCESSORIES	1-5
RECOMMENDED ACCESSORIES.	1-7
SECTION 2 OPERATING INSTRUCTIONS	
CONTROLS AND CONNECTORS.	2-1
AMBIENT TEMPERATURE CONSIDERATIONS	2-1
FUNCTIONAL CHECK	2-1
Instruments Without Internal Sweep	2-4
Instruments With Internal Sweep (Optional 4)	2-6
DETAILED OPERATING INFORMATION	2-7
Signal Connectors	2-7
Input Signal Requirements	2-8
Input Attenuation	2-8
Remote Program Connector	2-8
Care of Storage Screen	2-9
Storage Operation	2-9
Option 4 Sweep Information	2-9
SECTION 3 INSTRUMENT OPTIONS	
CHANGE INFORMATION	

LIST OF ILLUSTRATIONS

FIGURE NO.		PAGE
Frontis-piece	607 Storage Monitor	iv
1-1	Dimensional drawing	1-6
2-1	Location and function of front-panel controls.	2-2
2-2	Location and function of rear-panel controls and connectors	2-3
2-3	REMOTE PROGRAM connector data	2-9
2-4	Measurement lines on the 607 graticule	2-10

LIST OF TABLES

TABLE NO.		PAGE
1-1	Shipping Carton Test Strength	1-1
1-2	Electrical Characteristics.	1-2
1-3	Environmental Characteristics	1-5
1-4	Physical Characteristics.	1-5
3-1	Option Information Locator	3-2