



**PLEASE CHECK FOR CHANGE INFORMATION
AT THE REAR OF THIS MANUAL.**

**2337
OSCILLOSCOPE
OPERATORS**

**Tektronix, Inc.
P.O. Box 500
Beaverton, Oregon 97077**

070-4119-00
Product Group 40

INSTRUCTION MANUAL

Serial Number _____ First Printing SEP 1981
Revised FEB 1986

Copyright © 1981 Tektronix, Inc. All rights reserved.
Contents of this publication may not be reproduced in any
form without the written permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered
by U.S. and foreign patents and/or pending patents.

TEKTRONIX, TEK, SCOPE-MOBILE, and  are
registered trademarks of Tektronix, Inc. TELEQUIPMENT is
a registered trademark of Tektronix U.K. Limited.

Printed in U.S.A. Specification and price change privileges
are reserved.

INSTRUMENT SERIAL NUMBERS

Each instrument has a serial number on a panel insert, tag,
or stamped on the chassis. The first number or letter
designates the country of manufacture. The last five digits
of the serial number are assigned sequentially and are
unique to each instrument. Those manufactured in the
United States have six unique digits. The country of
manufacture is identified as follows:

B000000	Tektronix, Inc., Beaverton, Oregon, USA
100000	Tektronix Guernsey, Ltd., Channel Islands
200000	Tektronix United Kingdom, Ltd., London
300000	Sony/Tektronix, Japan
700000	Tektronix Holland, NV, Heerenveen, The Netherlands

TABLE OF CONTENTS

	Page		Page
LIST OF ILLUSTRATIONS	iii	OPERATING CONSIDERATIONS	20
LIST OF TABLES	v	GRATICULE	20
OPERATORS SAFETY SUMMARY	vi	GROUNDING	20
INTRODUCTION	1	SIGNAL CONNECTIONS	21
PREPARATION FOR USE	2	INPUT COUPLING CAPACITOR PRECHARGING	21
LINE VOLTAGE SELECTION	2	INSTRUMENT COOLING	22
LINE FUSE	4	INSTRUMENT FAMILIARIZATION	23
POWER CORD	5	INTRODUCTION	23
CONTROLS, CONNECTORS, AND INDICATORS	6	EQUIPMENT REQUIRED	23
POWER AND DISPLAY	6	NORMAL SWEEP DISPLAY	24
VERTICAL	7	DISPLAYING A SIGNAL	26
HORIZONTAL	10	OPERATOR'S CHECKS AND ADJUSTMENTS	36
A TRIGGER	12	INTRODUCTION	36
B TRIGGER	15	TRACE ROTATION	36
REAR PANEL	18	PROBE COMPENSATION	37
		ASTIGMATISM	38
		VERTICAL GAIN CHECK	39

TABLE OF CONTENTS (cont)

	Page		Page
BASIC APPLICATIONS	40	Rise Time	61
NONDELAYED MEASUREMENTS	40	Time Difference Between Repetitive Pulses	63
AC Peak-to-Peak Voltage	40	Time Difference Between Two Time-Related Pulses.	65
Instantaneous DC Voltage	42	DMM DISPLAYS AND MEASUREMENTS	67
Algebraic Addition	43	Resistance	67
Common-Mode Rejection	45	RMS AC	67
Time Duration	46	DC Volts	68
Frequency	48	OPTIONS	69
Rise Time	48	OPTION 03	69
Time Difference Between Two Time-Related Pulses.	50	SPECIFICATION	70
Phase Difference	51	ACCESSORIES	99
Amplitude Comparison.	53	STANDARD ACCESSORIES INCLUDED	99
Time Comparison	55	OPTIONAL POWER CORDS.	99
DELAYED-SWEEP MAGNIFICATION	57	APPENDIX A	100
Magnified Sweep Runs After Delay	57	CHANGE INFORMATION	
Pulse Jitter Time Measurement.	59		
Triggered Magnified Sweep	60		
DELAYED-SWEEP TIME MEASUREMENTS	60		
Time Duration	61		

LIST OF ILLUSTRATIONS

Figure		Page
	The 2337 Oscilloscope	viii
1	LINE VOLTAGE SELECTOR switch, line fuse, and power cord	3
2	Optional power cords.	5
3	Power and display controls and indicators	7
4	Vertical controls, connectors, and indicators and calibrator output	8
5	Horizontal controls and indicator	10
6	A TRIGGER controls, connector, and indicator	13
7	DMM and B TRIGGER controls, connectors, and LCD readout	16
8	Rear-panel connectors	19
9	Graticule measurement markings	20
10	Initial setup for instrument familiarization procedure.	27
11	Probe compensation.	38
12	Vertical display accuracy	39
13	Peak-to-peak waveform voltage	41
14	Instantaneous voltage measurement	43
15	Algebraic addition	45
16	Common-mode rejection.	46
17	Time duration.	47

LIST OF ILLUSTRATIONS (cont)

Figure		Page
18	Rise time	49
19	Time difference between two time-related pulses.	51
20	Phase difference	53
21	High-resolution phase difference.	53
22	Delayed-sweep magnification.	58
23	Pulse jitter	59
24	Time duration using delayed sweep.	62
25	Rise time, differential time method.	63
26	Time difference between repetitive pulses	64
27	Time difference between two time-related pulses.	66

LIST OF TABLES

Table		Page
1	Line Voltage and Fuse Selection	4
2	Option 03 Line Voltage and Fuse Selection	4
3	DMM Autoranging	17
4	Equipment Required for Instrument Familiarization Procedure	24
5	Electrical Characteristics	72
6	Environmental Characteristics	95
7	Physical Characteristics	97
8	Option Electrical Characteristics	98

OPERATORS SAFETY SUMMARY

The general safety information in this part of the summary is for both operating and servicing personnel. Specific warnings and cautions will be found throughout the manual where they apply and do not appear in this summary.

Terms in This Manual

CAUTION statements identify conditions or practices that could result in damage to the equipment or other property.

WARNING statements identify conditions or practices that could result in personal injury or loss of life.

Terms as Marked on Equipment

CAUTION indicates a personal injury hazard not immediately accessible as one reads the markings, or a hazard to property, including the equipment itself.

DANGER indicates a personal injury hazard immediately accessible as one reads the marking.

Symbols in This Manual



This symbol indicates where applicable cautionary or other information is to be found. For maximum input voltage see Table 5.

Symbols as Marked on Equipment



DANGER – High voltage.



Protective ground (earth) terminal.



ATTENTION – Refer to manual.