

492AP SPECTRUM ANALYZER

Qservice sample File

Please Check for CHANGE INFORMATION at the Rear of This Manual

First Printing DEC 1985
Revised FEB 1986

PREFACE

This manual is one of a set of product manuals for the TEKTRONIX 492AP Programmable Spectrum Analyzer. This manual describes the programmable functions of the spectrum analyzer and how to use them for remote operation. The manual organization is shown in the Table of Contents. The manuals that are available now in addition to this Programmers Manual are the

- 492A/492AP Operators Manual (standard accessory),
- 492A/492AP Service Manuals, Volume 1 and 2 (standard accessories),
- 492A/492AP Operators Handbook (optional accessory), and
- 490AP-Series Programmers Reference Guide (optional accessory).

For manual ordering information, contact your local Tektronix Field Office or representative or refer to the Accessories portion of the Replaceable Mechanical Parts list in the Service Manual, Volume 2.

Standards and Conventions Used

Most terminology is consistent with standards adapted by IEEE and IEC. A glossary of terms is provided in Appendix A. Abbreviations in the documentation are consistent with ANSI Y1.1-1972. GPIB functions conform to the IEEE 488-1978 Standard and the Tektronix Interface Standard for GPIB Codes, Formats, Conventions, and Features. Copies of ANSI and IEEE standards can be ordered from the Institute of Electrical and Electronic Engineers Inc. Contact your local Tektronix Field Office or representative if you have questions regarding the Tektronix reference document.

Change/History Information

Any change information that involves manual corrections or additional information is located behind the tabbed Change Information page at the back of this manual.

History information, as well as the updated data, is combined within this manual when the page(s) is revised. A revised page is identified by a revision date located in the lower inside corner of the page.

Unpacking and Initial Inspection

Instructions for unpacking and preparing the instrument for use are described in Section 3 of the Operators Manual.

Storage and Repackaging

Instructions for short- and long-term storage and instrument repackaging for shipment are described in Section 3 of the Operators Manual.

TABLE OF CONTENTS

Page		Page
	Section 3	DEVICE-DEPENDENT MESSAGE STRUCTURE AND EXECUTION
PREFACE.....		Syntax Diagrams.....3-1
TABLE OF CONTENTS.....		Spectrum Analyzer Input Messages.....3-1
LIST OF ILLUSTRATIONS.....		Input Message Format.....3-1
LIST OF TABLES.....		Message Unit Delimiter (;).....3-2
SAFETY SUMMARY.....		Message Terminator (TERM).....3-2
		Format Characters.....3-2
Section 1	INTRODUCTION TO GPIB OPERATION	Input Buffering and Execution.....3-2
	GPIB Pushbutton and Indicators.....1-1	Command Format.....3-2
	RESET TO LOCAL/REMOTE.....1-1	Header.....3-2
	<Blue-SHIFT> PLOT.....1-1	Header Delimiter (SP).....3-2
	<Green-SHIFT> SRQ.....1-1	Argument Delimiter (,).....3-2
	ADDRESSED.....1-2	Argument Format.....3-3
	GPIB Function Readout.....1-1	Numbers.....3-3
	Setting the GPIB ADDRESS Switches 1-2	Units.....3-3
	Setting the LF OR EOI Switch.....1-3	Character Argument.....3-3
	Setting the TALK ONLY and LISTEN	Link Argument.....3-3
	ONLY Switches.....1-3	String Argument.....3-3
	IEEE 488 Functions.....1-4	Query Format.....3-4
	Source Handshake (SH1).....1-4	Query Response Format.....3-4
	Acceptor Handshake (AH1).....1-4	Binary Block.....3-4
	Talker (T5).....1-4	End Block.....3-4
	Listener (L3).....1-4	Spectrum Analyzer Output Messages.....3-4
	Service Request (SR1).....1-5	Output Message Format.....3-4
	Remote/Local (RL1).....1-5	Output Message Execution.....3-4
	Parallel Poll (PP1).....1-5	490P/490AP-Series Compatibility.....3-4
	Device Clear (DC1).....1-5	GPIB.....3-5
	Device Trigger (DT1).....1-5	DEGAUS Command.....3-5
	Controller (C0).....1-5	IDENT Command.....3-5
	Connecting to a System.....1-5	PEAK Command.....3-5
		Readout Maximum.....3-5
		Service Requests.....3-5
		Affect of Busy on Device-
Section 2	GETTING STARTED	Dependent Messages.....3-5
	Setting and Querying	GET (Group Execute Trigger).....3-5
	Programmable Controls.....2-1	EVENT?/ERR? Codes.....3-5
	Setting Programmable Controls.....2-1	Preserving Frequencies.....3-6
	Querying Programmable Controls.....2-2	MINATT Command.....3-6
	Exercise Routines.....2-3	Reference Level.....3-6
	Talk/Listen.....2-3	RDOUT Command.....3-6
	Acquiring Instrument Settings	
	with the SET Query.....2-3	Section 4
	Resetting the Spectrum Analyzer	INSTRUMENTCONTROL
	and Interface Messages.....2-4	Frequency.....4-3
	Acquiring a Waveform.....2-4	FREQ.....4-3
	Getting Smarter.....2-4	TUNE.....4-4
	Getting Smarter Another Way.....2-5	TMODE.....4-4
		FIRST.....4-5
		SECOND.....4-5
		DISCOR.....4-5
		FRQRNG.....4-6
		STEP.....4-6
		MSTEP.....4-7

	Page		Page
Section 4 (continued)		Section 5 MARKER SYSTEM	
PSTEP.....	4-7	Waveform Finding	5-1
STSTOP	4-7	System Control.....	5-1
DELFR.....	4-8	MARKER	5-1
DEGAUS	4-8	MTRACE	5-2
EXMXR.....	4-8	M1ASGN	5-3
IMPED.....	4-9	M2ASGN	5-3
Frequency Span and Resolution.....	4-10	NSELVL.....	5-4
SPAN	4-10	SGTRAK.....	5-4
ZEROSP.....	4-11	Marker Positioning	5-5
MXSPN.....	4-12	DPMK.....	5-5
RESBW	4-12	MAMPL?	5-5
ARES.....	4-13	MCEN	5-6
IDENT.....	4-13	MCPOIN.....	5-6
Vertical Display and Reference Level....	4-15	MEXCHG.....	5-6
VRTDSP	4-16	MFREQ	5-6
REFLVL.....	4-16	MKDP.....	5-7
RLUNIT	4-17	MLOCAT?	5-7
CAL	4-18	MTOP.....	5-8
ENCAL	4-19	MTUNE.....	5-8
FINE	4-20	Marker Finding	5-8
RLMODE.....	4-20	HRAMPL	5-8
PEAK.....	4-21	LRAMPL	5-9
MINATT.....	4-21	BWNUM	5-9
MAXPWR	4-22	BWMODE.....	5-10
RFATT?.....	4-22	MFBIG.....	5-10
PLSTR.....	4-23	MLFTNX.....	5-11
VIDFLT.....	4-23	PKFIND	5-11
Sweep Control.....	4-24	MMAX	5-11
TRIG.....	4-24	MMIN	5-12
SIGSWP	4-25	MRGTNX.....	5-12
TIME.....	4-26	THRHLDB.....	5-13
Digital Storage.....	4-27	MVLFDB.....	5-13
AVIEW.....	4-27	MVRTDB	5-14
BVIEW.....	4-28	STYPE.....	5-14
SAVEA	4-28	SGERR.....	5-18
BMINA.....	4-29	Miscellaneous.....	5-19
DSTORE.....	4-29	ZOOM	5-19
DRECAL.....	4-29		
MXHLD.....	4-30	Section 6 DISPLAY DATA AND CRT READOUT I/O	
CRSOR.....	4-30	Waveform Transfers	6-1
Display Control.....	4-32	WFMPRE.....	6-1
REDOUT.....	4-32	CURVE	6-3
GRAT	4-33	WAVFRM	6-4
CLIP	4-33	DPRE?	6-4
General Purpose.....	4-34	DCOPY?.....	6-5
HDR	4-34	Crt Readout Transfers.....	6-5
HELP?	4-35	RDOUT.....	6-5
STORE	4-35	TEXT	6-6
RECALL	4-35	UPRDO	6-6
PLOT?	4-35	MDRDO.....	6-6
PTYPE.....	4-36	LORDO.....	6-7
POFSET	4-36		

	Page		Page
Section 7		Section 9	
WAVEFORM PROCESSING		(continued)	
Waveform Finding	7-1	Multiple Use of Display Buffer	9-6
POINT	7-1	Buffer Data Flow	9-6
FIBIG	7-2	Order-Dependent Conflicts.....	9-6
LFTNXT.....	7-2	Finding Signals with Waveform	
RGTNXT.....	7-2	Processing	9-7
FMAX	7-2	Understanding How Waveform	
FMIN	7-2	Processing Works	9-7
Data Point Commands Interaction	7-2	Setting the Threshold.....	9-8
CENSIG.....	7-3	Acquiring Data for Waveform	
TOPSIG.....	7-3	Processing	9-8
		Spectrum Search	9-8
Section 8		Using MCEN.....	9-9
SYSTEM COMMANDS AND QUERIES		High Center Frequency Drift Rate	
Instrument Parameters.....	8-1	After Tuning	9-9
SET?	8-1	Spectrum Search Using Repeat	9-9
INIT	8-6	Messages on the Crf Using RDOUT.....	9-9
ID?	8-6	Using CAL Over the Bus	9-10
HDR	8-7	Comparing FREQ and TUNE	9-10
Message Execution.....	8-7	Comparing the Status Byte and the	
WAIT	8-7	ERR? Response	9-10
REPEAT	8-7	Execution and Transfer Times.....	9-11
Status and Error Reporting	8-8		
EOS.....	8-8	Appendix A	
RQS	8-8	IEEE STD 488 (GPIB) SYSTEM	
WARMSG.....	8-9	CONCEPTS	
Status Byte	8-9	Mechanical Elements	A-1
Effect of Busy on Device-		Electrical Elements.....	A-1
Dependent Messages	8-10	Functional Elements.....	A-1
Effect of Busy on Interface		A Typical GPIB System.....	A-2
Messages.....	8-10	Talkers, Listeners, and Controllers.....	A-2
DT	8-11	Interface Control Messages.....	A-2
EVENT?.....	8-11	Device-Dependent Messages	A-5
ALLEV?	8-11	GPIB Signal Line Definitions.....	A-6
NUMEV.....	8-11	Transfer Bus (Handshake).....	A-6
EVQTY?.....	8-12	Management Bus.....	A-6
TEST?	8-12	Interface Functions and Messages.....	A-8
Error Codes.....	8-13	RL (Remote-Local Function).....	A-8
		T/TE and L/LE (Talker and Listener	
Section 9		Functions).....	A-8
HELPS AND HINTS		SH and AH (Source and Acceptor	
Programming Techniques.....	9-1	Handshake Functions).....	A-9
Signal Processing	9-1	DC (Device Clear Function).....	A-9
Data Acquisition	9-1	DT (Device Trigger Function).....	A-9
Synchronizing Controller and		C, SR, and PP (Controller, Service	
Spectrum Analyzer.....	9-1	Request, and Parallel Poll	
Synchronizing with the Sweep	9-2	Functions).....	A-10
Using the End-of-Sweep SRQ.....	9-2	Taking Control (Asynchronous or	
INPUT: An SRQ Alternative.....	9-4	Synchronous.....	A-10
Binary Waveform Transfer.....	9-4	Passing Control	A-10
Getting Spectrum Analyzer Binary		Performing a Serial Poll.....	A-10
Curve Output.....	9-4		
Sending a Binary CURVE to the		Appendix B	
Spectrum Analyzer.....	9-4	INDEX AND PROGRAMMING	
Scaling, Saving, and Graphing		FUNCTIONS	
Waveform Data.....	9-5		
Saving the Scaled Array.....	9-5		
Storing Settings	9-5		
Using PLOT.....	9-5		

LIST OF ILLUSTRATIONS

Figure Number	Page	Figure Number	Page
TEKTRONIX 492AP Programmable Spectrum Analyzerviii		5-1	Using the PKFIND command5-12
1-1	GPIB pushbutton and indicators1-2	5-2	Locating the signal peak5-15
1-2	Status of active GPIB functions1-2	5-3	Signal finding examples5-16
1-3	Rear-panel GPIB ADDRESS switches1-3	5-4	Signal finding examples5-17
1-4	Effect of message terminator switch for input and output1-4	5-5	Signal finding example5-18
1-5	The rear-panel IEEE STD 488 PORT (GPIB)1-5	6-1	Waveform data related to the display6-5
1-6	The spectrum analyzer can be connected to a GPIB system in either a star or a linear pattern1-6	8-1	Test conversion chart8-13
4-1	Front-panel Frequency commands4-3	9-1	Synchronizing controller and spectrum analyzer for data acquisition9-3
4-2	Front-panel Frequency Span and Resolution commands4-10	9-2	How multiple use of the display data buffer is controlled9-7
4-3	Front-panel Vertical Display and Reference Level commands4-15	A-1	IEEE Std 488 (GPIB) connectorA-1
4-4	Front-panel Sweep Control commands4-24	A-2	A typical GPIB systemA-3
4-5	Front-panel Digital Storage commands4-27	A-3	ASCII & GPIB Code ChartA-4
4-6	Front-panel Display Control commands4-32	A-4	An example of data byte traffic on the GPIBA-7
4-7	Front-panel General Purpose commands4-34	A-5	A typical handshake timing sequenceA-7
		B-1	TEKTRONIX 492AP Programmable Spectrum AnalyzerB

LIST OF TABLES

Table Number	Page	Table Number	Page
1-1	Bus Addresses1-3	8-1	Instrument Functions8-6
1-2	Spectrum Analyzer IEEE 488 Interface Functions1-4	8-2	Warning Messages8-9
4-1	Front-panel Commands and Queries4-1	8-3	Test Conversion8-13
4-2	Frequency Span/Div Ranges4-11	8-4	Error and Event Codes8-15
4-3	Resolution Bandwidth Selection4-12	9-1	Execution Times9-11
4-4	Reference Level Settings4-17	9-2	4041 Transfer Times9-11
4-5	Calibration Codes4-19	A-1	Major GPIB Interface FunctionsA-2
5-2	Primary Marker Trace Organization5-2	A-2	Interface Messages and FunctionsA-5