

**Tektronix**<sup>®</sup>  
COMMITTED TO EXCELLENCE

**PLEASE CHECK FOR CHANGE INFORMATION  
AT THE REAR OF THIS MANUAL.**

**2465  
OSCILLOSCOPE  
OPERATORS**

INSTRUCTION MANUAL

Tektronix, Inc.  
P.O. Box 500  
Beaverton, Oregon 97077

070-3832-00  
Product Group 38

Serial Number \_\_\_\_\_

First Printing SEP 1982  
Revised AUG 1985

# TABLE OF CONTENTS

	Page		Page
LIST OF ILLUSTRATIONS . . . . .	ii	<b>SECTION 5 OPERATOR'S CHECKS AND ADJUSTMENTS</b>	
LIST OF TABLES . . . . .	ii	INTRODUCTION . . . . .	5-1
OPERATORS SAFETY SUMMARY . . . . .	iii	INITIAL SETUP . . . . .	5-1
		TRACE ROTATION ADJUSTMENT . . . . .	5-1
<b>SECTION 1 SPECIFICATION</b>		ASTIGMATISM ADJUSTMENT . . . . .	5-2
INTRODUCTION . . . . .	1-1	AUTO DC BALANCE ADJUSTMENT . . . . .	5-2
PERFORMANCE CONDITIONS . . . . .	1-1	PROBE LOW-FREQUENCY COMPENSATION . . . . .	5-2
		MATCHING CHANNEL 2 DELAY . . . . .	5-3
<b>SECTION 2 PREPARATION FOR USE</b>		AMPLITUDE CHECK . . . . .	5-4
SAFETY . . . . .	2-1	TIMING CHECK . . . . .	5-4
LINE VOLTAGE SELECTION . . . . .	2-1	<b>SECTION 6 BASIC APPLICATIONS</b>	
LINE FUSE . . . . .	2-1	INDEX OF PROCEDURES . . . . .	6-1
POWER CORD . . . . .	2-1	VOLTAGE MEASUREMENT . . . . .	6-1
INSTRUMENT COOLING . . . . .	2-1	VOLTAGE RATIO . . . . .	6-2
START-UP . . . . .	2-2	ALGEBRAIC ADDITION AND ELIMINATING COMMON-MODE SIGNALS . . . . .	6-3
REPACKAGING FOR SHIPMENT . . . . .	2-2	TIME INTERVAL . . . . .	6-4
		FREQUENCY . . . . .	6-4
<b>SECTION 3 CONTROLS, CONNECTORS, AND INDICATORS</b>		TIME DIFFERENCE BETWEEN TWO TIME-RELATED PULSES . . . . .	6-5
POWER AND DISPLAY . . . . .	3-1	TIME RATIO . . . . .	6-5
VERTICAL . . . . .	3-2	PHASE DIFFERENCE BETWEEN TWO TIME-RELATED SIGNALS . . . . .	6-6
HORIZONTAL AND DELTA MEASUREMENT . . . . .	3-4	SMALL-ANGLE PHASE DIFFERENCE . . . . .	6-6
TRIGGER . . . . .	3-7	DELAYED-SWEEP OPERATION . . . . .	6-7
REAR PANEL . . . . .	3-9		
READOUT DISPLAY . . . . .	3-11	<b>SECTION 7 OPTIONS AND ACCESSORIES</b>	
		INTRODUCTION . . . . .	7-1
<b>SECTION 4 OPERATING CONSIDERATIONS</b>		OPTION 11 . . . . .	7-1
GRATICULE . . . . .	4-1	OPTION 1R . . . . .	7-1
TIME AND VOLTAGE MEASUREMENTS . . . . .	4-1	POWER CORD OPTIONS . . . . .	7-1
GROUNDING . . . . .	4-1	STANDARD ACCESSORIES . . . . .	7-2
SIGNAL CONNECTIONS . . . . .	4-2	OPTIONAL ACCESSORIES . . . . .	7-2
INPUT-COUPLING CAPACITOR PRECHARGING . . . . .	4-2	<b>APPENDIX A POWER-UP TESTS</b>	
EXTERNAL TRIGGERING . . . . .	4-2	KERNEL TESTS . . . . .	A-1
		CONFIDENCE TESTS . . . . .	A-1
		<b>CHANGE INFORMATION</b>	

# LIST OF ILLUSTRATIONS

Figure		Page
	The 2465 Oscilloscope . . . . .	iv
2-1	Line selector switch, line fuse, and detachable power cord. . . . .	2-2
3-1	Power and display controls . . . . .	3-1
3-2	Vertical controls and CH 1 OR X and CH 2 connectors. . . . .	3-2
3-3	Channel 3 and Channel 4 controls and connectors and CALIBRATOR output . . . . .	3-3
3-4	Horizontal and delta measurement controls . . . . .	3-4
3-5	Trigger controls and indicators. . . . .	3-7
3-6	Rear-panel controls and connectors. . . . .	3-10
3-7	Readout display locations . . . . .	3-11
4-1	Graticule measurement markings . . . . .	4-1
5-1	Probe low-frequency compensation. . . . .	5-3
6-1	Instantaneous dc levels. . . . .	6-1
6-2	Voltage ratios. . . . .	6-2
6-3	Eliminating common-mode signals . . . . .	6-3
6-4	Measuring rise times. . . . .	6-4
6-5	Time difference between two time-related pulses (cursor method) . . . . .	6-5
6-6	Time ratios (duty cycles) . . . . .	6-6
6-7	Phase difference between two time-related signals . . . . .	6-7
6-8	Small-angle phase difference . . . . .	6-7
6-9	Time difference between two time-related pulses (delayed-sweep method) . . . . .	6-9

# LIST OF TABLES

Table		Page
1-1	Electrical Characteristics. . . . .	1-2
1-2	Environmental Characteristics . . . . .	1-9
1-3	Mechanical Characteristics. . . . .	1-10
2-1	Voltage, Fuse, and Power-Cord Data . . . . .	2-3
A-1	Confidence Test Numbers and Descriptions . . . . .	A-1