



Qservice - 2710 Users manual Sample - Qservice

2710

Spectrum Analyzer
User's Guide

2710

Spectrum Analyzer
User's Guide

Tektronix[®]

Tektronix[®]
COMMITTED TO EXCELLENCE

Table of Contents

Introduction 1-1

- Using This Manual 1-1
- Typographical conventions 1-3
- What is a Spectrum Analyzer? 1-5
- What Can You Do with a Spectrum Analyzer? 1-8
- About the 2710 1-8

Getting Started 2-1

- Precautions 2-1
- Turning on the 2710 2-3
- Restoring the Factory Default Settings 2-4
- The Spectral Display 2-4
- The Control Panel 2-7
- Sounds 2-9
- The Built-in Calibrator 2-10
- Making Your First Measurement 2-11

The Controls 3-1

- Fundamental Operations 3-1**
 - Frequency Span/Division 3-2
 - Maximum Span 3-3
 - Zero Span 3-3
 - Center Frequency Control 3-4
 - Reference Level, Higher - Lower 3-5
 - Reference Level, 1dB/10dB per Step 3-6
- Enhanced Versatility 3-7**
 - Resolution Bandwidth, Wider - Narrower 3-7
 - Resolution Bandwidth, AUTO Mode 3-9
 - Resolution Bandwidth, Video Filter 3-10
 - Vertical Scale, 10dB/5dB/1dB per Step 3-12
 - Vertical Scale, LIN 3-13

Qservice-2710Users manual Sample - Qservice

Sweep, FAST - SLOW	3-14
Sweep, AUTO Mode	3-15
Sweep, SGL SWP	3-16
Sweep, LEVEL	3-17
Display Storage and the Analog Display	3-18
Display Storage, SAVE	3-20
Display Storage, Waterfall Mode	3-22
Display Storage, MAX HOLD	3-24
Frequency/Markers, MKR/ Δ /Off	3-25
Frequency/Markers, CTR MEAS/TRKG	3-28
Frequency/Markers, Next Peak Right/Left	3-32
Frequency/Markers, MKR PEAK FIND	3-33
Miscellaneous Controls	3-33
Graticule Illumination	3-34
INTENSITY	3-34
TRACE ROT, VERT POS, HORIZ POS	3-35
The Menus -- Ultimate Flexibility	4-1

Input Menu	4-7
Turning the Calibrator On and Off	4-7
Changing the Reference Level	4-8
Setting the RF Attenuation	4-8
Changing Reference Level Units	4-9
Accommodating External Amplification/Attenuation	4-10
Accommodating a 75 Ohm Source	4-11
Setting the First Mixer Input Level	4-13
Turning the Preamplifier On and Off	4-14
Using the dBUV/M	4-15
Marker/Frequency Menu	4-25
Setting the Center Frequency Using the MKR/FREQ MENU	4-25
Setting the Span/Division Using the MKR/FREQ MENU	4-26
Using the Keypad to Set Start and Stop Frequencies	4-26
Using Markers to Set Start and Stop Frequencies	4-27
Transposing Markers	4-27
Changing the Knob Function	4-28

Qservice 2710 Users Manual Sample - Qservice

Moving the Marker to the Next Higher or Lower Peak	4-29
Marker to the Reference Level	4-30
Selecting the Tuning Increment	4-31
Center or Start Frequency	4-32
Setting the Signal Threshold	4-32
Counter Resolution	4-33
Programmed Tuning	4-34
Tabular Tuning	4-35
Frequency Offsets	4-36
Display Menu	4-38
Ensemble Averaging	4-38
Subtracting Stored Signals	4-43
Changing Acquisition Mode	4-47
Activating Minimum Hold	4-48
Adding Titles and Labels	4-49
Turning the On-screen Readouts On and Off	4-51
The Display Line and Limit Detector	4-52
Measuring Frequency Deviation	4-54
Measuring Percent Modulation	4-57
Displaying an External Source	4-58
Applications Menu	4-58
Measuring Occupied Bandwidths	4-59
Measuring Average Noise	4-60
Measuring Carrier to Noise Ratios	4-61
Searching for Signals	4-63
Detector/Generator Menu	4-66
Listening to FM Transmissions	4-66
Listening to AM Transmissions	4-67
Listening to FM or AM Transmissions	4-67
Utility Menu	4-68
Keypad Entered Control Settings	4-68
Recalling Last Power-Down Settings	4-70
User-Defined Power-Up Settings	4-70
Other User-Defined Settings	4-71
Normalizing the 2710	4-72
System Configuration	4-75
The Communications Port	4-75

Qservice-2710 Users manual Sample - Qservice

Selecting the Screen Plotter	
Configuration	4-75
Selecting the Printer Configuration	4-76
Instrument Configuration	4-76
The Audio Alert Level	4-77
Setting the Minimum Signal Size	4-77
Sending Waveforms to a Computer	4-78
Turning Phase Lock On and Off	4-78
Turning Frequency Corrections	
On and Off	4-79
The Spectral Display in Menus	4-79
Changing the Sweep Holdoff	4-80
Setting the Date and Time	4-80
Protecting Stored Settings	4-80
Confirming Installed Options	4-81
Instrument Diagnostics and Adjustments	4-81
Aligning the Display with the Screen	4-82
Service Normalizations	4-82
If You Lose NVRAM	4-84
Plotting the Displayed Waveform	4-85
Sweep/Trigger Menu	4-87
Free Running the Sweep Generator	4-87
"Oscilloscope" Trigger Modes	4-87
TV Line Triggering	4-90
TV Video Field Triggering	4-93
Setting the Sweep Rate	4-93
Manually Scanning	4-94
The Video Monitor	4-94
User-Definable Key	4-97

Qservice - 2710 User's Manual Sample - Qservice

External I/O 5-1

Mains Power 5-1
J101 -- TV Sideband Adapter Interface 5-1
J102 -- External Trigger 5-2
J103 -- Accessory Connector 5-3
Pin 1 -- Video Input 5-3
Pin 2 -- Chassis and Signal Ground 5-4
Pin 3 -- Video Output 5-5
Pin 6 -- Sweep Gate 5-5
Pin 7 -- Sweep Ramp 5-7

**Appendix A -- Broadcast AM, FM, and
TV signal sources A-1**

Appendix B -- Error Messages. B-1

Index I-1

Qservice - 2710 Users manual Sample - Qservice

List of Illustrations and Tables

Illustrations

Figure 1-1. Spectrum analyzer block diagram (late model)	1-1
Figure 2-1. 2710 display with factory power-up settings	2-5
Figure 2-2. 2710 calibration signal and harmonics	2-2
Figure 2-3. Calibration signal and second harmonic	2-14
Figure 3-1. Example of a waterfall display	3-23
Figure 4-1. The 2710 menu hierarchy	4-2, 4-3
Figure 4-2. The Input Menu	4-4
Figure 4-3. Reference Level Units Menu	4-5
Figure 4-4. 75/50 ohm matching minimum loss pad	4-13
Figure 4-5. Equipment setup for field strength measurements	4-18
Figure 4-6. Average signal plus noise and average signal plus noise subtracted from the current sweep	4-44
Figure 4-7. Average MEAN noise and MAX HOLD signal plus noise spectra	4-45
Figure 4-8. B, C MINUS A OFFSET TO CENTER	4-46
Figure 4-9. B, C MINUS A OFFSET TO TOP	4-47
Figure 4-10. 2710 plot with title and plot label	4-51
Figure 4-11. Portion of US broadcast FM band	4-55
Figure 4-12. Instantaneous frequency deviation and maximum observed deviation	4-56
Figure 4-13. Frequency deviation by MAX HOLD technique	4-57
Figure 4-14. The SIGNAL SEARCH frequency range	4-64
Figure 4-15. Typical plotter output from the 2710 showing a broadcast television spectrum	4-86
Figure 4-16. Video field using internal or TV field triggering	4-89
Figure 4-17. Video signal using continuous horizontal line triggering	4-91
Figure 4-18. Video signal using knob-selectable horizontal line triggering	4-92
Figure 4-19. 2710 screen in video monitor mode	4-96
Figure 5-1. Sweep gate and ramp timing	5-6

Tables

Table 2-1. Effect of arrow keys.	2-8
Table 3-1. Display register status.	3-19
Table 4-1. Units associated with the letter-keys.	4-5
Table 4-2. Equivalent decibel - voltage values.	4-19

Qservice - 2710 Users manual Sample - Qservice