

**Tektronix®**  
COMMITTED TO EXCELLENCE

**PLEASE CHECK FOR CHANGE  
INFORMATION AT THE REAR  
OF THIS MANUAL.**

**434**  
**OSCILLOSCOPE**  
**OPERATORS**

**Tektronix, Inc.**  
**P.O. Box 500**  
**Beaverton, Oregon 97077**

070-1142-01

**INSTRUCTION MANUAL**  
First Printing AUG 1971  
Serial Number \_\_\_\_\_ Revised AUG 1981

# TABLE OF CONTENTS

	Page		Page
<b>Introduction</b>			
General .....	1	Vertical GAIN .....	16
Operating Voltage .....	1	ASTIGmatism and FOCUS .....	16
Operating Temperature .....	2	Basic Timing .....	16
Operating Position .....	2	<b>Applications</b>	
<b>Controls and Connectors</b>		General .....	16
General .....	2	DC Voltage Level Measurement .....	17
Detailed .....	3	Peak-To-Peak Voltage Measurement – AC .....	18
<b>Basic Operation</b>		Comparison Measurements .....	20
General .....	10	Time-Duration Measurements .....	22
Non-Store Display .....	10	Frequency Measurement .....	24
Magnified Sweep Display .....	11	Risetime Measurements .....	24
External Horizontal Display .....	11	Time-Difference Measurements .....	25
Normal Storage Display .....	12	Multi-Trace Difference Measurements .....	27
Single-Sweep Storage .....	12	X-Y Phase Measurement .....	29
Integrated Fast-Rise Waveforms .....	13	Common-Mode Rejection .....	30
Fast Single-Sweep Enhancement .....	13		
<b>User's Calibration</b>			
General .....	15	<b>Abbreviations and symbols used in this manual are based on or taken directly from IEEE Standard 260 'Standard Symbols for Units', MIL-STD-12B and other standards of the electronics industry. Change information, if any, is located at the rear of this manual.</b>	
Trace Rotation .....	15		
STEP ATTENuator BALance .....	15		
Probe Compensation .....	15		