



222 HANDHELD DIGITAL STORAGE OSCILLOSCOPE

TABLE OF CONTENTS

	Page
LIST OF ILLUSTRATIONS	v
LIST OF TABLES	vi
OPERATORS SAFETY SUMMARY	vii
Section 1 YOUR NEW OSCILLOSCOPE	
1.1 FEATURES	1-1
1.2 SPECIFICATION SUMMARY	1-2
1.3 STANDARD ACCESSORIES	1-4
1.4 OPTIONAL ACCESSORIES	1-4
Section 2 GETTING STARTED	
2.1 SAFETY	2-1
2.2 BATTERY-CHARGER ADAPTER	2-1
2.3 EXTERNAL SUPPLY VOLTAGE	2-1
2.4 BATTERY OPERATION	2-2
2.5 FIRST TIME BATTERY OPERATION	2-3
2.6 START-UP	2-4
2.7 AUTO TIMEOUT	2-4
2.8 VIEWING A SIGNAL QUICKLY	2-4
Section 3 WHAT THE CONTROLS DO	
3.1 CONTROL REFERENCE TABLES	3-1
3.2 ON-SCREEN READOUT LOCATIONS	3-6
3.3 EXPANDED CONTROLS INFORMATION	3-8
3.4 CRT DISPLAY, MENU BUTTONS, AND POWER	3-8
3.5 VERTICAL CONTROLS	3-10
3.6 HORIZONTAL CONTROLS	3-12
3.7 TRIGGER CONTROLS	3-14
3.8 TOP PANEL BUTTONS	3-16
3.9 REAR PANEL CONTROLS AND CONNECTORS	3-19

Section 4 HOW IT WORKS

4.1	TURN ON	4-1
4.2	AUTO SETUP	4-1
4.3	MENU SELECTION	4-2
4.4	STORE OR NONSTORE DISPLAY MODE SELECTION	4-3
4.5	MENU AND SAVED WAVEFORM DISPLAYS CLEARING	4-3
4.6	CHANNEL SELECTION	4-3
4.7	VERTICAL INPUT COUPLING	4-4
4.8	VOLTS/DIV SCALING	4-5
4.9	VERTICAL POSITIONING	4-5
4.10	VARIABLE VOLTS/DIV CONTROL	4-6
4.11	CH1 AND CH2 INVERTED DISPLAY	4-6
4.12	SEC/DIV SCALING	4-7
4.13	HORIZONTAL POSITIONING	4-8
4.14	X10 MAGNIFICATION	4-8
4.15	TRIGGER LEVEL SETTING	4-9
4.16	TRIGGER SLOPE SELECTION	4-9
4.17	TRIGGER MODE SETTING	4-10
4.18	TRIGGER SOURCE SELECTION	4-11
4.19	SAVING WAVEFORMS	4-12
4.20	RECALLING SAVED WAVEFORMS	4-13
4.21	SAVING FRONT-PANEL SETUPS	4-14
4.22	RECALLING FRONT-PANEL SETUPS	4-16
4.23	CLEARING SAVED FRONT-PANEL SETUPS ..	4-17
4.24	SETTING TRIGGER POSITION	4-17
4.25	ACQUISITION MODE SELECTION	4-20
4.26	X-Y OR Y-T DISPLAY MODE SELECTION	4-21
4.27	READOUT ON OR OFF	4-21
4.28	AUTO TIMEOUT	4-22
4.29	SETTING BAUD RATE	4-24
4.30	DISPLAY XY ROTATION ALIGNMENT	4-25
4.31	SELF CALIBRATION	4-27
4.32	FIRMWARE VERSION IDENTIFICATION	4-30

Section 5 MAKING MEASUREMENTS

- 5.1 SIGNAL TRACING WITH AUTO SETUP 5-1
- 5.2 GRATICULE MEASUREMENTS 5-4
- 5.3 FLOATING MEASUREMENTS 5-6
- 5.4 DIFFERENTIAL MEASUREMENTS 5-6
- 5.5 SINGLE SWEEP OPERATION 5-8

Section 6 MORE ON HOW IT WORKS

- 6.1 AUTO SETUP 6-1
- 6.2 PROBES 6-3
- 6.3 STORE AND NONSTORE DISPLAY MODES ... 6-5
- 6.4 VERTICAL INPUT COUPLING 6-5
- 6.5 DEFAULT ACQUISITION MODES 6-6
- 6.6 TRIGGER MODES 6-10
- 6.7 TRIGGER SOURCE 6-12
- 6.8 TRIGGER POSITION 6-12
- 6.9 TRIGGER LEVEL/AUTO LVL: PUSH 6-13
- 6.10 ACQUISITION MODES 6-13
- 6.11 TIPS ON BATTERY CARE 6-14
- 6.12 ALTERNATE METHOD FOR BATTERY CHARGING 6-15
- 6.13 BATTERY REPLACEMENT 6-15
- 6.14 REPACKAGING FOR SHIPMENT 6-17

Section 7 OPTIONS AND ACCESSORIES

- 7.1 INTRODUCTION 7-1
- 7.2 STANDARD ACCESSORIES 7-1
- 7.3 OPTIONAL ACCESSORIES 7-1
- 7.4 OPTIONS 7-2
- 7.5 PARTS SUPPLIED WITH THE 222ACC FIELD ACCESSORIES KIT 7-2

Section 8 PERFORMANCE SPECIFICATIONS

- 8.1 INTRODUCTION 8-1
- 8.2 RECOMMENDED PERFORMANCE CHECK SCHEDULE 8-1

8.3 DETAILED SPECIFICATIONS 8-1
8.3.1 Vertical Deflection System 8-1
8.3.2 Trigger System 8-6
8.3.3 Horizontal System 8-6
8.3.4 X-Y Operation 8-8
8.3.5 RS-232 Interface 8-8
8.3.6 External Power Requirements 8-8
8.3.7 Internal Batteries 8-9
8.4 ENVIRONMENTAL SPECIFICATIONS 8-10
8.5 MECHANICAL SPECIFICATIONS 8-12

Appendix A CHECKING YOUR INSTRUMENT'S PERFORMANCE

A.1 INTRODUCTION A-1
A.2 TEST EQUIPMENT REQUIRED A-1
A.3 PERFORMANCE CONDITIONS A-3
A.4 PERFORMANCE CHECK INTERVAL A-3
A.5 PREPARATION A-4
A.6 INDEX TO PERFORMANCE CHECKS A-5
A.7 DISPLAY CHECKS A-6
A.8 VERTICAL A-8
A.9 HORIZONTAL A-15
A.10 TRIGGER A-17

INDEX

CHANGE INFORMATION

LIST OF ILLUSTRATIONS

-- Qservice -- Hyperlinked Page Scroll Up or Down Left click to select -- Qservice --

2-1	External Power Input	2-2
3-1	Front-Panel controls	3-1
3-2	Top-Panel buttons	3-3
3-3	Rear Panel	3-4
3-4	On-screen readout locations	3-6
3-5	CRT display, menu buttons, and power	3-8
3-6	Probes and Vertical controls	3-10
3-7	Horizontal controls	3-12
3-8	Trigger controls	3-14
3-9	Top-Panel buttons	3-16
3-10	Rear Panel	3-19
4-1	ALIGN XY test pattern	4-27
5-1	Peak-to-peak voltage measurement	5-2
5-2	Voltage with respect to ground	5-3
5-3	Time measurement	5-4
5-4	Rise Time measurement	5-5
5-5	Common-mode rejection with differential inputs	5-7
6-1	Probes and probe accessories	6-4
8-1	Maximum rated normal-mode voltage versus frequency derating curve	8-4
8-2	Maximum rated common-mode voltage versus frequency derating curve	8-5
A-1	Trigger jitter check	A-22

-- Qservice -- Hyperlinked Page Scroll Up or Down Left click to select -- Qservice --

LIST OF TABLES

-- Qservice -- Hyperlinked Page Scroll Up or Down Left click to select -- Qservice --

Table		Page
3-1	Front-Panel Controls Quick Reference	3-2
3-2	Top-Panel Controls Quick Reference	3-3
3-3	Rear-Panel Controls Quick Reference	3-4
3-4	On-Screen Readouts	3-7
6-1	AUTO SETUP Defaults	6-2
6-2	Default Acquisition Modes	6-7
6-3	Repetitive Store Fill	6-10
6-4	AUTO LVL Trigger Interval Limits	6-11
A-1	Test Equipment Required	A-2
A-2	VOLTS/DIV Accuracy Settings	A-12

-- Qservice -- Hyperlinked Page Scroll Up or Down Left click to select -- Qservice --