

## **Service VOL 2**



**2794 Series**  
**Spectrum Analyzers**

**070-8637-00**

Please check for change information at the rear of this manual.



# Table of Contents

The 2794 Service Manual is divided into two volumes. Refer to the **2794 Service Manual, Volume 1** for all specifications, maintenance procedures, and parts lists.

<b>Preface</b> .....	i
<b>Table of Contents</b> .....	iii
<b>List of Figures</b> .....	vii
<b>Servicing Safety Summary</b> .....	ix
<b>Symbols and Terms</b> .....	x
<b>Specific Precautions</b> .....	x
<b>Diagrams</b> .....	9-1
<b>Symbols</b> .....	9-1
<b>Component Values</b> .....	9-1
<b>Graphic Items and Special Symbols Used in This Manual</b> ...	9-2
<b>Component Locator Diagrams</b> .....	9-2
<b>Block Diagram &amp; Interconnect</b>	
<b>System Functional Block Diagram, B</b> ◊	0
<b>RF Deck Interconnect, B</b> ◊	1
<b>Options Interconnect, B</b> ◊	2
<b>Mother Board, A28</b> ◊, ◊	1, 2
<b>1st Converter</b>	
<b>1st Converter Block Diagram, B</b> ◊	3
<b>1st LO, 1st Converter, A16</b> ◊	1
<b>2nd Converters</b>	
<b>2nd Converters Block Diagram, B</b> ◊	4
<b>2nd Converter, A18</b> ◊	1
<b>16-20 MHz Phase Locked 2nd LO, A22A1</b> ◊	1
<b>Phase Locked 2nd LO &amp; 2200 MHz Ref/Converter, A22A2</b> ◊	2
<b>719 MHz 2nd LO, A23A1</b> ◊	1
<b>25 MHz Phase Lock, A23A2</b> ◊	2
<b>829 MHz Harmonic Mixer, A23A3</b> ◊	3
<b>829 MHz Diplexer, A23A4</b> ◊	4
<b>829 MHz Amplifier, A23A5</b> ◊	5

110 MHz IF Select, A23A6 ◊ 6

829 MHz 2nd Converter, A23A7 ◊ 7

**3rd Converter**

3rd Converter Block Diagram, B ◊ 5

110 MHz IF Amplifier, A32 ◊ 1

110 MHz IF Out (Option 42 Only), A32 ◊ 1

3rd Converter, A34 ◊ 1

Reference Lock, A36 ◊ 1

**IF Section**

IF Section Block Diagram, B ◊ 6

VR Mother Board #1, A68A1 ◊ 1

VR Mother Board #2, A68A2 ◊ 2

VR Input, A68A3 ◊ 3

VR 1st Filter Select, A68A4 ◊ 4, ◊ 5

VR 10 dB Gain Steps, A68A5 ◊ 6

VR 20 dB Gain Steps, A68A6 ◊ 7

VR Band Leveling, A68A7 ◊ 8

VR 2nd Filter Select, A68A8 ◊ 9, ◊ 10

Post VR Amplifier, A68A9 ◊ 11

10/100 Hz 1st Mixer, A69A1 ◊ 1

10/100 Hz Bandpass Filter, A69A2 ◊ 2

10/100 Hz 2nd Mixer, A69A3 ◊ 3

10/100 Hz Local Oscillator, A69A4 ◊ 4

Log Amplifier, Detector, & Video Amplifier, A62 ◊ 1, ◊ 2, ◊ 3, ◊ 4

**Display Control Section**

Display Control Section Block Diagram, B ◊ 7

Video Processor, A40 ◊ 1

Horizontal Digital Storage, A60 ◊ 1, ◊ 2









Vertical Digital Storage, A61 ◊ 1, ◊ 2

Deflection Amplifiers, A64 ◊ 1, ◊ 2

CRT Readout, A66 ◊ 1, ◊ 2

Z-Axis, RF Interface, & Power Status, A70 ◊ 1, ◊ 2

High Voltage, A74 ◊ 1

**Frequency Control Section**Frequency Control Section Block Diagram, B Sweep, A72   Span Attenuator, A48 1st LO Driver, A44  Center Frequency Control, A46  Preselector Driver, A42 **Counter & Phase Lock Section**Counter & Phase Lock Section Block Diagram, B Phase Gate Detector, A24 Harmonic Mixer, A25 Auxiliary Synthesizer, A26  Phase Lock Synthesizer, A50A1 Strobe Driver, A50A2 Offset Mixer, A50A3 Error Amplifier, A50A4 Controlled Oscillator, A50A5 Counter, A51  **Digital Control Section**Digital Control Section Block Diagram, B Front Panel, A38   Processor, A58  Memory, A54  ROM Banks & GPIB, A56  GPIB Interface, A30A57 Accessories Interface, A30A76 **Power Supply Section**Power Supply Section Block Diagram, B Main Power Supply, A30A1  Fan Drive, A30A2 



# List of Figures

Figure 9-1: Graphic Items and Special Symbols Used in This Manual .....	9-2
Figure 9-2: Locating Components on Circuit Board or Schematic Diagram .....	9-3
Figure 9-3: Other Parts Component Locator .....	9-4
Figure 9-4: A16A1, A18A1, and A19 .....	9-5
Figure 9-5: A22A1 16-20 MHz Phase Lock .....	9-6
Figure 9-6: A22A2A1 2182 MHz Microstrip Oscillator .....	9-7
Figure 9-7: A22A2A2 2200 MHz Reference .....	9-8
Figure 9-8: A22A2A3 2200 MHz Reference Mixer .....	9-9
Figure 9-9: A23A1 719 MHz 2nd LO .....	9-10
Figure 9-10: A23A2 25 MHz Phase Lock .....	9-11
Figure 9-11: A23A3 829 MHz Harmonic Mixer .....	9-12
Figure 9-12: A23A4 829 MHz Diplexer and A23A5 829 MHz Amplifier .....	9-13
Figure 9-13: A23A6 110 MHz IF Select and A23A7 829 MHz 2nd Converter .....	9-14
Figure 9-14: A26A1 Auxiliary Synthesizer .....	9-15
Figure 9-15: A26A1 Component Locator .....	9-16
Figure 9-16: A30A1 Main Power Supply .....	9-17
Figure 9-17: A30A1 Component Locator .....	9-18
Figure 9-18: A30A2 Fan Drive .....	9-19
Figure 9-19: A30A3 EMI Filter .....	9-20
Figure 9-20: A30A76 Accessories Interface and A32 110 MHz Amplifier .....	9-21
Figure 9-21: A34A1 100 MHz Osc. and 3rd Converter .....	9-22
Figure 9-22: A34A3A1 50/75 $\Omega$ Cal Out .....	9-23
Figure 9-23: A36A1 Reference Lock .....	9-24
Figure 9-24: A38 Front Panel (Front) .....	9-25
Figure 9-25: A38 Front Panel (Back) .....	9-26
Figure 9-26: A38 Front Panel Component Locator .....	9-27
Figure 9-27: A40 Video Processor .....	9-28
Figure 9-28: A40 Component Locator .....	9-29
Figure 9-29: A42 Preselector Driver .....	9-30
Figure 9-30: A42 Component Locator .....	9-31
Figure 9-31: A44A1 1st LO Driver .....	9-32
Figure 9-32: A44A1 Component Locator .....	9-33
Figure 9-33: A46 Center Frequency Control .....	9-34
Figure 9-34: A46 Component Locator .....	9-35
Figure 9-35: A48A1 Span Attenuator .....	9-36
Figure 9-36: A50A1 Synthesizer .....	9-37

## List of Figures

Figure 9-37: A50A2 Strobe Driver .....	9-38
Figure 9-38: A50A3 Offset Mixer .....	9-39
Figure 9-39: A50A4 Error Amplifier .....	9-40
Figure 9-40: A50A5 Controlled Oscillator .....	9-41
Figure 9-41: A51A1 Counter .....	9-42
Figure 9-42: A51A1 Component Locator .....	9-43
Figure 9-43: A54 Memory .....	9-44
Figure 9-44: A56 ROM Banks & GPIB .....	9-45
Figure 9-45: A56 ROM Banks & GPIB Component Locator .....	9-46
Figure 9-46: A58 Processor .....	9-47
Figure 9-47: A58 Component Locator .....	9-48
Figure 9-48: A60 Horizontal Digital Storage .....	9-49
Figure 9-49: A61 Vertical Digital Storage .....	9-50
Figure 9-50: A62 Log and Video Amplifier .....	9-51
Figure 9-51: A62 Component Locator .....	9-52
Figure 9-52: A62 Component Locator (Cont.) .....	9-53
Figure 9-53: A64 Deflection Amplifier .....	9-54
Figure 9-54: A64 Component Locator .....	9-55
Figure 9-55: A66 CRT Readout .....	9-56
Figure 9-56: A66 Component Locator .....	9-57
Figure 9-57: A68A1 VR Mother #1 .....	9-58
Figure 9-58: A68A2 VR Mother #2 .....	9-59
Figure 9-59: A68A3 VR Input .....	9-60
Figure 9-60: A68A4 VR 1st Filter Select .....	9-61
Figure 9-61: A68A4 Component Locator .....	9-62
Figure 9-62: A68A5 VR 10dB Gain Steps .....	9-63
Figure 9-63: A68A6 VR 20 dB Gain Steps .....	9-64
Figure 9-64: A68A7 VR Band Leveling .....	9-65
Figure 9-65: A68A8 2nd Filter Select .....	9-66
Figure 9-66: A68A8 Component Locator .....	9-67
Figure 9-67: A68A9 Post VR Amplifier .....	9-68
Figure 9-68: A69A1 1st Mixer .....	9-69
Figure 9-69: A69A2 10 Hz/100 Hz Bandpass Filter .....	9-70
Figure 9-70: A69A3 2nd Mixer and A69A4 Local Oscillator .....	9-71
Figure 9-71: A70 Z-Axis, RF Interface and Power Status .....	9-72
Figure 9-72: A70 Component Locator .....	9-73
Figure 9-73: A72 Sweep .....	9-74
Figure 9-74: A72 Component Locator .....	9-75
Figure 9-75: A74 High Voltage .....	9-76

