


TEK

OPERATOR'S MANUAL  
070-6717-00

# 2205 OSCILLOSCOPE




Qservice ----- This Document is a complete scan from the Original Tektronix Manual ----- Qservice

**Tektronix**<sup>®</sup>  
COMMITTED TO EXCELLENCE

Copyright © 1987 Tektronix, Inc. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered by U.S. and foreign patents issued and pending.

Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX, TEK, PLOT 10, TEKTEST, SCOPE-MOBILE, and  are registered trademarks. For further information, contact Tektronix, Inc. Corporate Offices, P.O. Box 500, Beaverton, OR 97077. Phone: (503) 627-7111; TWX: (910)467-8708; TLX: 151754. Subsidiaries and distributors worldwide.

Printed in Hong Kong.

### INSTRUMENT SERIAL NUMBERS

Each instrument has a serial number on a panel insert, tag, or stamped on the chassis. The first number or letter designates the country of manufacture. The last five digits of the serial number are assigned sequentially and are unique to each instrument. Those manufactured in the United States have six unique digits.

B000000	Tektronix, Inc., Beaverton, Oregon, U.S.A.
HK00001	Hong Kong
100000	Tektronix Guernsey, Ltd., Channel Islands
200000	Tektronix United Kingdom, Ltd., London
300000	Sony/Tektronix, Japan
700000	Tektronix Holland, NV, Heerenveen, The Netherlands

# CONTENTS

	Page
Operator's Safety Summary .....	iv
The 2205 Oscilloscope .....	vii
 <b>SECTION 1—PREPARATION FOR USE</b>	
Safety .....	1-1
Line Voltage Selection .....	1-1
Line Fuse .....	1-4
Power Cord .....	1-4
Instrument Cooling .....	1-4
Initial Start-Up .....	1-5
 <b>SECTION 2—OPERATION</b>	
Front Panel Organization .....	2-1
Controls, Connectors, and Indicators .....	2-1
Learning the Controls .....	2-6
Display Controls .....	2-8
Vertical Controls .....	2-8
Input Coupling .....	2-8
Channel Selection .....	2-9
Add and Invert .....	2-9
Chop or Alt? .....	2-9
Horizontal Controls .....	2-10
Sweep Speed Selection .....	2-10
Magnifying Waveform Details .....	2-10

## SECTION 2—OPERATION (CONTINUED)

Trigger Controls .....	2-10
Which Mode to Use .....	2-11
Source .....	2-12
Slope .....	2-12
Level .....	2-12
Connecting Signals .....	2-12
Waveform Fidelity and Probe Grounds .....	2-13
Probe Compensation .....	2-13
Probe Handling .....	2-13
Coaxial Cables .....	2-14

## SECTION 3—APPLICATIONS

Amplitude Measurements .....	3-1
Peak-to-peak Voltage .....	3-1
Instantaneous Voltage .....	3-3
Algebraic Addition .....	3-5
Common-mode Rejection .....	3-6
Amplitude Comparison (Ratio) .....	3-7
Time Measurements .....	3-8
Time Duration .....	3-8
Period and Frequency .....	3-10
Rise Time .....	3-10
Time Difference Between Pulses on Time-Related Signals .....	3-12
Phase Difference .....	3-14
Television Displays .....	3-17
TV Field Signals .....	3-17
TV Line Signals .....	3-18
Z-Modulation .....	3-18

## SECTION 4—CHECKS AND ADJUSTMENTS

Trace Rotation .....	4-1
Probe Compensation .....	4-1

**SECTION 5—PERFORMANCE CHARACTERISTICS**

**SECTION 6—OPTIONS AND ACCESSORIES**

Standard Accessories .....	6-1
Options .....	6-1
Optional Accessories .....	6-4

**APPENDIX A – Magnified Sweep Speeds**

**APPENDIX B – Repackaging for Shipment**

**APPENDIX C – Glossary**