

# 2430A

## DIGITAL OSCILLOSCOPE USER REFERENCE GUIDE



Copyright © 1987 Tektronix, Inc. All rights reserved.  
Contents of this publication may not be reproduced in any  
form without the written permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered  
by U.S. and foreign patents and/or pending patents.

TEKTRONIX, TEK, SCOPE-MOBILE, and  are  
registered trademarks of Tektronix, Inc.

Printed in U.S.A. Specification and price change privileges  
are reserved.

### INSTRUMENT SERIAL NUMBERS

Each instrument has a serial number on a panel insert, tag,  
or stamped on the chassis. The first number or letter  
designates the country of manufacture. The last five digits  
of the serial number are assigned sequentially and are  
unique to each instrument. Those manufactured in the  
United States have six unique digits. The country of  
manufacture is identified as follows:

B000000	Tektronix, Inc., Beaverton, Oregon, USA
100000	Tektronix Guernsey, Ltd., Channel Islands
200000	Tektronix United Kingdom, Ltd., London
300000	Sony/Tektronix, Japan
700000	Tektronix Holland, NV, Heerenveen, The Netherlands

# Contents

	<i>Page</i>
Illustrations .....	iii
<b>1 Getting Started/Front Panel</b>	
Getting Started .....	1
Front Panel .....	3
<b>2 CRT Readout Display</b>	
CRT Readout Display .....	4
<b>3 Status/Help Menu</b>	
Status/Help Menu .....	5
<b>4 Powering Up</b>	
Powering Up .....	7
<b>5 CRT Display Menus</b>	
CRT Display Menus .....	9
<b>6 Auto Setup</b>	
Auto Setup .....	11
<b>7 PRGM Auto stop</b>	
PRGM Auto stop .....	12
<b>8 Measure</b>	
Measure .....	15
<b>9 Output</b>	
Output .....	19
<b>10 Vertical</b>	
Vertical .....	21

**Contents**

---

<b>11</b>	<b>Horizontal</b>	
	Horizontal.....	24
<b>12</b>	<b>Cursors</b>	
	Cursors .....	25
<b>13</b>	<b>Delay Functions</b>	
	Delay Functions .....	28
<b>14</b>	<b>Triggering</b>	
	Triggering .....	30
<b>15</b>	<b>A Triggering</b>	
	A Triggering .....	34
<b>16</b>	<b>B Triggering</b>	
	B Triggering .....	36
<b>17</b>	<b>Acquisition</b>	
	Acquisition .....	39
<b>18</b>	<b>Save and Display Reference</b>	
	Save and Display Reference .....	41
<b>19</b>	<b>GPIB Status</b>	
	GPIB Status.....	43

Qservice - samples - Qservice

## Illustrations

<b>Figure</b>		<b>Page</b>
1	Front Panel Buttons and Controls.....	3
2	CRT Readout Display .....	4
3	Status Menu Display.....	5
4	POWER and MENU OFF Button.....	7
5	INTENSITY Control, SELECT and STATUS/HELP Buttons.....	11
6	AUTO SETUP Button .....	12
7	PRGM Button.....	15
8	MEASURE Button.....	19
9	OUTPUT Button.....	21
10a	Vertical Buttons and Controls .....	22
10b	Vertical Buttons and Controls .....	24
11	Horizontal Buttons and Controls .....	25
12	Cursor Buttons and Controls .....	29
13	Delay Buttons and Controls .....	30
14	Trigger CPLG, SET VIDEO, and SET WORD Buttons .....	32
15	Trigger SOURCE, INIT @50%, and TRIG STATUS Buttons.....	34
16	A Trigger MODE, TRIG POSITION, A/B TRIG Buttons.....	36
17	B Trigger A/B TRIG, CPLG, INIT @50% MODE, TRIG POSITION SOURCE Buttons .....	39
18	Storage ACQUIRE Button .....	41
19	Storage SAVE and DISPLAY REF Button.....	

Qservice - samples - Qservice