

---

**TEK**

---

070-6338-01  
Product Group 37

# **2430A PROGRAMMERS REFERENCE GUIDE**

*Please Check for  
CHANGE INFORMATION  
at the Rear of This Manual*

---

First Printing FEB 1989

**Tektronix**<sup>®</sup>  
COMMITTED TO EXCELLENCE

# Table of Contents

	<i>Page</i>
List of Illustrations .....	vi
List of Tables .....	vi
Operators Safety Summary .....	vii
<b>1 Introduction</b>	
How to Use this Guide.....	1-1
Tips for New Users.....	1-2
<b>2 Establishing GPIB Communication</b>	
Setting the GPIB Mode.....	2-1
Talk-Only .....	2-1
Listen-Only.....	2-2
Talk-Listen .....	2-3
Devices .....	2-3
Off Bus.....	2-3
Setting the GPIB Message Terminator .....	2-4
Which terminator should you choose? .....	2-4
Setting the GPIB Primary Address.....	2-5
Sample Controller Program .....	2-6
Debugging the Interface.....	2-7
GPIB Status Menu .....	2-7
What Do the GPIB Status LED's Mean? .....	2-8
<b>3 How to Write Programs</b>	
Sending a Command to the 2430A.....	3-1
Building Commands .....	3-1
Composing Messages.....	3-3
Terminating Messages.....	3-3
Asking the 2430A a Question.....	3-4
Using PATH Mode .....	3-4
Using LONG Mode.....	3-5
How to Use Service Requests (SRQs) .....	3-5
Programming With SRQs.....	3-6
Programming Without SRQs .....	3-8
Making Measurements With the 2430A.....	3-9
Using the WPE Feature.....	3-9
Making Custom Measurements.....	3-14
The Vertical Window for Making Measurements .....	3-16
How to Use the 2430A AutoStep Sequencer.....	3-17
Constructing a Sequence.....	3-17
Recalling a Sequence.....	3-20

### 3 *How to Write Programs (cont)*

Removing Unwanted Sequences.....	3-20
Using the Sequencer.....	3-21
Sending and Receiving Sequences .....	3-22
Making Printer or Plotter Copies.....	3-25
Making Copies Without a Controller .....	3-26
Making Copies With a Controller.....	3-28
Save-On-Delta Hard Copies .....	3-30
Special HC100 Mode .....	3-30
How to Save Instrument Settings .....	3-32
Power-up Default Setups.....	3-32
Using a Controller .....	3-32
Using the Sequencer.....	3-34
Using Group Execute Trigger .....	3-34

### 4 *Debugging Your Programs*

Familiarization .....	4-1
Interacting With the Display.....	4-2
Character Update Rate.....	4-3
Using the 2430A as a Bus Monitor.....	4-3

### A *GPIB Commands*

Vertical Commands.....	A-1
Trigger Commands .....	A-4
Horizontal Commands .....	A-10
Acquisition Commands.....	A-13
Saveref Commands .....	A-15
Display Commands.....	A-17
Cursor Commands.....	A-19
Automatic Feature Commands.....	A-22
Sequencer Commands .....	A-27
Output Commands .....	A-31
Miscellaneous Commands.....	A-32
Waveform Commands .....	A-35
Waveform Data Commands .....	A-41
Service Request Commands.....	A-44
Calibration and Diagnostic Commands.....	A-46

### B *Discussion on Waveforms*

Doing a Waveform Transfer .....	B-1
From the 2430A to a Controller.....	B-1
From the Controller to the 2430A.....	B-2
From 2430A to 2430A .....	B-3

**B Discussion on Waveforms (cont)**

Waveform Data Formats .....	B-4
Data Point Representation.....	B-5
ASCII Format Encoding .....	B-6
Binary Formats.....	B-8
Scaling the Data Points .....	B-13
Sample Conversion to Volts .....	B-13
Waveform Acquisition and Conversion Programming Example.....	B-16

**C Event Tables**

2430A Status Bytes .....	C-1
Command Error Events.....	C-2
Execution Error Events.....	C-3
Internal Errors .....	C-4
System Messages .....	C-4
User Request Events.....	C-5
Probe Identify Events .....	C-5
Operation Complete Events .....	C-6
Execution Warning.....	C-6
Device Dependent Message.....	C-8
Fatal Error .....	C-8

**D GPIB Concepts**

Mechanical .....	D-1
Allowable Configurations .....	D-1
Restrictions.....	D-1
Electrical Elements.....	D-2
Functional Elements.....	D-3
Acceptor Handshake (AH).....	D-3
Source Handshake (SH).....	D-3
Listener (L) and Listener Extended (LE) .....	D-3
Talker (T) and Talker Extended (TE) .....	D-3
Device Clear (DC).....	D-3
Device Trigger (DT) .....	D-4
Remote/Local (RL).....	D-4
Service Request (SR).....	D-4
Parallel Poll (PP).....	D-4
Controller (C) .....	D-4
Instrument Addresses.....	D-5
Primary Address.....	D-5
Listen Address.....	D-5
Talk Address .....	D-5
Secondary Address.....	D-5
GPIB Buses.....	D-6
Data Bus.....	D-6
Management Bus .....	D-7
Handshake Bus.....	D-8

**D GPIB Concepts (cont)**

GPIB Communication Protocol.....	D-8
Controllers .....	D-8
Talkers .....	D-9
Listeners .....	D-10
Universal Commands .....	D-10
Device Clear (DCL).....	D-10
Local Lockout (LLO).....	D-11
Serial Poll Disable (SPD).....	D-11
Serial Poll Enable (SPE).....	D-11
Unlisten (UNL) .....	D-11
Untalk (UNT).....	D-11
Addressed Commands.....	D-12
Group Execute Trigger (GET) .....	D-12
Go To Local (GTL) .....	D-12
Selected Device Clear (SDC) .....	D-12
Take Control (TCT) .....	D-12
Serial Polling.....	D-13
Status Bytes.....	D-13
Requesting Service .....	D-13
Conducting Serial Polls .....	D-14

**E Init Settings and Power Up Status**

**F ASCII and 2430A Character Charts**

**G Answers to Common Questions**

Who Can I Call for Help? .....	G-1
How Do I Unlock the Front Panel?.....	G-1
What Does a 255 (FFh) in My Data Stream Mean? .....	G-1
How Do I Get Just the Answer From a 2430A Query?.....	G-1
How Do I Clear All SRQ's and Event Codes? .....	G-1
Can I Run Self-Cal From a Controller? .....	G-2
How Can I Get the Most Recent GPIB Related Status?.....	G-2
How Do I Get All the Measurements at Once?.....	G-2
How Do I Clear the Screen? .....	G-2
How Do I Clear One Line of Text? .....	G-2
How Do I Write Text to the Screen?.....	G-2
How Do I Write My Own Menus and Handle Them? .....	G-3
Why Do I Keep Getting Event 459, SRQ Pending?.....	G-3
How Do I Send a Sequence From One 2430A to Another? .....	G-3
How Do I Print Out a Status, Help, or Snapshot Screen?.....	G-3
Why Does the Acquisition Restart When I Send Certain Commands? .....	G-3

**G Answers to Common Questions (cont)**

Why Doesn't the Waveform I Sent to the 2430A Look Like  
the One I Took Out? ..... G-4

Why are the Abbreviations of Symbols on the 2430A Not  
the Same as Other Tektronix Oscilloscopes ..... G-4

Why Would I Use the INIT Command? ..... G-4

Do Sequences Go Away When I Turn Power Off?..... G-4

Can I Access a Step in the Middle of a Sequence? ..... G-4

Why Do I Only Get Part of the Response to a SET? Query? ..... G-5

How Can I Tell When a Command Has Been Executed? ..... G-5

**H 2430A Specific Information**

Talked With Nothing to Say ..... H-1

Accepting Numbers..... H-1

Accepting Characters..... H-1

Power-Up Sequence of the 2430A..... H-2

**I How to Use Fast Transmit Mode**

How to Set Up Fast Transmit ..... I-1

Potential Traps..... I-3

    Controller Program Hangs ..... I-3

    2430A Hangs..... I-4

Fast Transmit Transfer Rates ..... I-4

Some Points to Remember ..... I-6

**J Example Programs**

Talker-Listener Program for HP Basic ..... J-1

Talker-Listener Program for IBM Basic ..... J-2

Pulse Counting Program..... J-3

Extended Accuracy Timing Measurement Program ..... J-5

**Index**

---

## ***Illustrations***

<b><i>Figure</i></b>	<b><i>Page</i></b>
D-1 GPIB connector.....	D-2
D-2 GPIB Buses.....	D-6

## ***Tables***

<b><i>Table</i></b>	<b><i>Page</i></b>
B-1 ASCII Waveform Transfer.....	B-7
B-2 Binary Waveform Transfer.....	B-9
B-3 Partial Binary Waveform Transfer.....	B-12